



Robert Davis Performing Arts Center BRANSCOMB MEMORIAL AUDITORIUM

GPS Address:
1085 Johnson Ave.
Lakeland, FL 33801

Mailing Address:
111 Lake Hollingsworth Drive
Lakeland, FL 33801

TECHNICAL SPECIFICATIONS

DIRECTIONS TO BRANSCOMB MEMORIAL AUDITORIUM

FROM:

TAMPA – I-4 East to Exit 28 (Memorial Blvd.); Memorial Blvd. to S. Florida Avenue (SR 37); Right on Florida, continue to Belmar Street; Left on Belmar Street to Lake Hollingsworth Drive; Left on Lake Hollingsworth Drive to first driveway on left past Johnson Avenue; Take driveway to Branscomb Memorial Auditorium loading dock.

ORLANDO/ DAYTONA BEACH – I-4 West to Exit 32 (Florida Avenue/ SR 37); South on SR 37 to Belmar Street (approx. 9 miles); Left on Belmar Street to Lake Hollingsworth Drive; Left on Lake Hollingsworth Drive to first driveway on left past Johnson Avenue; Take driveway to Branscomb Memorial Auditorium loading dock.

JACKSONVILLE – I-95 South to I-4 West and follow directions from Orlando/ Daytona Beach.

MIAMI/ FT. LAUDERDALE – I-95 North to I-4 West and follow directions from Orlando/ Daytona Beach; or Florida Turnpike North to Yeehaw Junction (SR 60); SR 60 West to Bartow; in Bartow take U.S. 98 North (Bartow Road); U.S. 98 North to N. Crystal Lake Drive (approx. 10 miles); Left on N. Crystal Lake Drive; Continue until N. Crystal Lake Drive dead ends into Lake Hollingsworth Drive; Right on Lake Hollingsworth Drive; Continue around lake on Lake Hollingsworth Drive (campus and auditorium will be visible on right; auditorium is large white building on hill); Take driveway to Branscomb Memorial Auditorium Loading dock or right on Johnson Ave to enter front “Robert Davis Performing Arts Center – Honeyman Pavilion” Lobby.

AUDITORIUM SEATING

Total: 1,760 (and 8 handicapped)

Main Floor:

<u>Section</u>	<u>Rows</u>	<u>Number of Seats</u>
Center	A through GG	369
Right	A through GG	373
Far Right	H through GG	157
Left	A through GG	373
Far Left	H through GG	158
Main Floor Total:		1,430

Balcony:

<u>Section</u>	<u>Rows</u>	<u>Number of Seats</u>
Center	A through G	98
Right	A through H	69
Far Right	A through J	46
Left	A through J	71
Far Left	A through J	46
Balcony Total:		330

THEATRICAL LIGHTING EQUIPMENT INVENTORY (Revised 8/1/2018)

Light Board: ETC Element 250 channel, computer, with 134-2.4kW ETC Sensor dimmers

HOUSE AUDIO SYSTEM

Our self-powered *Meyer* speaker system is digitally processed through an *Allen & Heath AHM-32*, with an S-Link digital connection to the mixing board.

Power:	240 volt, 200 amp, isolated supply
Mixing Board:	Allen & Heath SQ7 32-channel digital mixer
Playback:	Mac Mini with Q Lab
Speakers:	4 Meyer MSL-4 2 Meyer CQ-1 2 Meyer PSW-2 (Subwoofers) 4 Meyer UPM-1P (Front fill)

Speakers are cluster rigged above stage left, center, and stage right with down fill.

Stage Monitor (Self-powered):

2	Meyer UM-1P (Wedge)
---	---------------------

Please note: only the second floor chorus dressing rooms contain a stage monitor.

Microphone Input (32 total):

12	XLR inputs located SR
12	XLR inputs located SL
3	XLR inputs located DC (orchestra pit)
4	Shure QLX-D wireless handheld (SM58 or SM87) or bodypack units with lavaliers available. We have 2 Countryman E6 earsets in stock.

VIDEO SYSTEM

One Epson L1100U laser projector with long-throw lens (1920 x 1200, 6,000 lumens).

Projector is located in spotlight booth at rear of balcony, and throws to the front-projection screen (16' x 9') housed on Lineset 10. HDMI and VGA connections are available downstage right, or an HDMI connection is available at the lighting control booth.

LINE SET SCHEDULE

35 single purchase working lines, 8" on center

1. House Valence (red)
2. House Grand (red)
3. Black Legs
4. First Electric
- 5.
- 6.
- 7.
8. Black Border
9. Black Legs

CREW

Branscomb Memorial Auditorium is a non-union house. Yellow card requirements may or may

DRESSING ROOMS

Star Dressing Rooms (2): Stage right and stage left, on stage level, can each accommodate